







# PANELSAFE PS RANGE

## PS-SR225S & PS-SR225SS INSTALLATION GUIDE

### PS-SR225S & PS-SR225SS Seismount – 225mm

 <p><b>PS-SR225S</b></p> <p><b>PS-SR225SS</b></p>	<p><b>USE WITH:</b></p> <p><b>PC</b> Standard Range  <b>LP</b> Low Profile Range  <b>VL</b> Very Low Profile Range  <b>MC</b> Metal Range  <b>SL</b> Stratlock Range</p>	<p><b>INSTALL WITH:</b></p> <p>M10 pan head screw          6.3 x 8mm euro screw</p>
---	--	---


### INSTALLATION STEPS FOR WALLS

<p><b>1</b></p>  <p>PS-SR225S</p> <p>Fold tab over completely along dotted line</p>	<p><b>2</b></p>  <p>Wall substrate</p> <p>PC-F1A female clip</p>	<p><b>3</b></p>  <p>Panel</p> <p>PC-M1B male clips</p> <p>Measure 225mm below x-y point for location of PS-SR225S on panel</p>
<p><b>4</b></p>  <p>Screw folded end of PS-SR225S onto panel with 1 x 6.3 x 8mm Euro screw plus 2 x M8 pan-head screws</p> <p>Panel</p> <p>PS-SR225S</p> <p>Note: length of screws to suit panel thickness</p>	<p><b>5</b></p>  <p>Wall substrate</p> <p>Panel</p> <p>Wall substrate</p> <p>PC-F1A female clip</p>	<p><b>6</b></p>  <p>Wall substrate</p> <p>Clip panel in place</p> <p>PC-M1B male clips</p> <p>PS-SR225S</p>

# PANELSAFE PS RANGE

## PS-SR225S & PS-SR225SS INSTALLATION GUIDE

### PS-SR225S & PS-SR225SS Seismount – 225mm



#### USE WITH:

**PC** Standard Range  
**LP** Low Profile Range  
**VL** Very Low Profile Range  
**MC** Metal Range  
**SL** Stratlock Range

#### INSTALL WITH:

M10 pan head screw  
 6.3 x 8mm euro screw

### INSTALLATION STEPS FOR CEILINGS

<p><b>1</b></p> <p>Fold tab over completely along dotted line</p>	<p><b>2</b></p> <p>Partially screw M10 pan-head screw into substrate</p> <p>Mark position of PS-SR225S on panel</p> <p>40mm</p>	<p><b>3</b></p> <p>Screw folded end of PS-SR225S onto panel using 1 x 6.3 x 8mm Euro screw plus 2 x M8 pan-head screws</p> <p>Note: screw length to suit panel thickness</p>
<p><b>4</b></p> <p>Fold up SR and slot the PS-SR225S onto screw in substrate and tighten screw</p> <p>PC-M1B male clip</p>	<p><b>5</b></p> <p>Before pushing panel into position on substrate, ensure that PS-SR225S is bent inwards to ensure correct bending function when clipping panel into place inwards to encourage correct bend orientation</p> <p>PC-M1B male clip</p>	